



# Item No:946 Vespa 946 Electric Ride- On

Installation & operation Manual



**/!\ CAUTION:** 

ipsum

.This package contains small parts which are for adult assembly only. . Remove all plastic bags & tires before giving this toy to a child. .Protective equipment should be worn,not to be used in traffic. .Keep this instructions for future reference.


WARNING **ADULT ASSEMBLEY** REQUEST.

Vespa.® is a registered trademark owned by Piaggio & C.S.p.A. And used under license by Ningbo Prince Toys Co.,Ltd.

#### | . SPECIFICATIONS.


Suitable Ages	3-6 Years
Product Dimensions	108X49X75cm
Maximum Weight	30 kgs
Speed	2-3 km/h
Motor	30W
Charger	Input: AC 220V/110V
	Output:DC6V/500mA DC12V/700mA
Battery	6V4.5AH
Operating Ambient Temperature	0 - 40℃

#### . Components List



### ■. Assembly Instructions





4.Insert the front wheel stick

through the front fender.

7.Place the handle bar over

10.Insert the rear-view mirror


into the hole of the handle

bar.be certain the rear-view

mirrors are completely fixed.

the front wheel stick,insert

and tighten by the nut



2. Then tighten by two M4X14 screws both left and right side of the body.



rear of body, tighten by four M4X14 screws.



5.Insert the front wheel stick into the hole of the body,make



6.Connect the wire plug of the handle bar into the wire plug of plug into the hole of the body.



8. When the battery is installed,insert the red cable terminal into the battery



9.Place the seat into the location of the body, then tighten by one M4X14 screw



11.Place the windshild into the right position of the handlebar,then tighten by four M3X10 screws.

# VI. Battery and Charger Operating Guide

1. The charging socket is located at the left side of the motorcycle. 2. The battery and charger which are provided or recommended can be used only.
3. Please do not play with the charger and battery because they are not toys.

4. The battery charging operation is carried out only by adults but not children

**V. Function and Operation** 

3.Multi-media palyer


switch

4.Forward/Backward

1. Dash board

The battery shall be fully charged before first use; the battery charging time shall be 9-10 hours and can not exceed 15 hours.

The lukewarm phenomenon of the charger and battery will occur during charging.



2.Power ON/OFF

→ 5.Foot switch

### VII. Simple Fault Removal Guidance

Defective conditions	Key points of inspection
	Check the power switch, all plugs of the control plate under the seat, and the battery terminal line are properly inserted.
1. The ride-on not be driven.	Check the over current protector, when the car is over loaded or blocked, the over current protector automatically disconnects the circuit to protect the motor and controlling IC board.
	Check whether the car has been stored for a long time and its battery is not charged on time.
Music sound is distorted or silent	Check whether the battery has enough power, otherwise charge fully.

### VIII. WARNING

1) If the product is not used for a long time, please fully charge the battery and then turn off the power switch for storing the car. The battery shall be recharged once every other month, otherwise the battery service life will be shortened or the battery cannot be charged again.

2) Pay attention to the positive and negative poles of the battery during installation (the reverse connection or short circuit of the positive and negative poles of the battery is not allowed to occur).

### 2. Product warning:

1) There may be potential sharp edges, sharp points or small parts before the assembly of this product, and therefore this product shall be assembled by the adult.

2) To avoid suffocation, keep the plastic bag away from children. Dispose of all bags immediately.

3) The children shall correctly use the car under the adult guidance and supervision,otherwise they may make themselves or the others injured.

4) The car is suitable for being driven on the flat ground and strictly prohibited to be driven in such dangerous places as street, road, sleep slope and beside swimming pool,otherwise the traffic and drowning accidents may occur.

5) Please put on shoes and protection equipment before use, putting on the helmet, safety gloves, knee pads, etc. Imet, gloves, knee pads, etc.

6) Small parts possibly fall off when this product is used improperly. So, it is unsuitable for children under 36 months old. 7) Regularly check whether the battery, charger, wire, plug, casing and other parts are

8) This product is only allowed to be used by a child; the maximum load is 30kg, and therefore the overload is not allowed.

damaged; if the damage occurs, please cease to use this product until it has been repaired.

9) Keep away from fire.

10) The product instructions shall be kept as they contain important information.

### 3. WARNING:

## **⚠** WARNING

To reduce the risk of injury, adult supervision is required. Strictiy forbidden using on the roadways, near motor vehicles, slopes, swimming pools and where there is water; Please wear shoes; this toy car can only be used simultaneously by one

Keep away from kids before assembled by adult, as there are potentially sharp edges, points, or small parts.

## /!\ WARNING

Do not mix alkaline battery, standard (carbon-zinc) battery or rechargeable (nickel-cadmium) battery.



Protective equipment should be worn. Not to be used in traffic.



## 

This product is unsuitable for children under 3 years due to its maximum

### IX. Care and Maintenance

1) Regularly wipe and clean it with a piece of cloth.

2) The rotating parts of the car should be checked regularly to determine whether any foreign matter obstructs the rotation and to keep lubricating state of normal operation.

# WARRANTY REGISTRATION



O months warranty



Koopers Distribution Sdn Bhd

- **(2)** 03-78324338
- **@** www.koopers.co
- www.facebook.com/koopersmalaysia
- 40150 Shah Alam, Selangor